


NOTES: UNLESS OTHERWISE SPECIFIED  
 1. COCKPIT DESIGN IS GENERIC AND NOT AIRCRAFT SPECIFIC  
 2. -X REFERS TO ALL 107P-099 & 107P-100 SUB MODELS

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVAL
A	UPDATED TITLE BLOCK, MODEL NUMBERS, ADDED NOTE 2	01/03/05	CBKW



ITEM NO.	QTY	FSCM	PART OR IDENTIFYING NO.	NOMENCLATURE OR DESCRIPTION	MATERIAL SPECIFICATION	NOTE
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. TOLERANCES ARE FRACTIONS DECIMALS ANGLES						
MATERIAL			APPROVALS		DATE	
FINISH			DRAWN HEW		03/09/04	
DD NOT SCALE DRAWING			CHECKED		ENG	
APPLICATION			G.A.		SCALE NONE	

REV. A

SH. 2

DWG. NO. 6003

SIZE B


2

1

# INSTALLATION OF EVAS 107P-099-X & -100-X

NOTE: BEFORE INSTALLING EVAS, MEASURE THE HORIZONTAL WIDTH OF THE INSTRUMENT CLUSTER TO BE COVERED BY EVAS (SEE SKETCH BELOW).

THIS INSTRUMENT CLUSTER MUST NOT EXCEED 13.0" FOR THIS INSTALLATION. IF THE WIDTH EXCEEDS 13.0" CONTACT VISION SAFE CORP. FOR AN APPROPRIATE INFLATABLE VISION UNIT.



THE INFORMATION CONTAINED HEREIN IS PROPRIETARY AND CONFIDENTIAL TO VISION SAFE CORP., AND SHALL NOT BE DISCLOSED OR COPIED, IN WHOLE OR IN PART WITHOUT THE WRITTEN CONSENT OF VISION SAFE CORP.

2

1

B

A

SIZE	FSCM NO.	DWG NO.	REV
B		6003	A
SCALE N/A	LOCATION: 6003002A	SHEET 2 of 4	

2

1

### INSTALLATION OF EVAS 107P-099-X & -100-X

#### EVAS UNIT

1. EVAS MODELS 107P-099-X & -100-X ARE DESIGNED TO FIT THE PILOT FLIGHT DATA CASE WITHOUT ALTERATION. AS THE EVAS IS SELF-CONTAINED, NO ADDITIONAL INSTALLATION IS NEEDED.
2. THE INDICATED LOCATION IS A SUGGESTION. AS EVAS IS LOOSE EQUIPMENT, IT MAY BE STORED IN ANOTHER CONVENIENT LOCATION ACCESSIBLE TO THE PILOT. HOWEVER, PRIOR TO DEPLOYING EVAS, THE UNIT MUST BE ON THE OUTBOARD SIDE OF THE PILOT AND WITHIN ARMS REACH OF THE GLARE SHIELD.

#### VELCRD

1. CLEAN THE GLARE SHIELD TOP SURFACE FROM THE AFT EDGE FORWARD 5', AND 3' TO EACH SIDE OF THE LONGITUDINAL CENTERLINE THROUGH THE CONTROL WHEEL.
2. CEMENT 1"x5" LOOP VELCRD TO THE GLARE SHIELD. LOCATE THE VELCRD AS SHOWN ON SHEET 4 OF 4. USE DEVCON TWO-TON EPOXY CEMENT.

#### DOCUMENTATION

1. IN THE OPERATING MANUAL, FLIGHT MANUAL, OR CHECK LIST, AS APPROPRIATE, ADD "DEPLOY EVAS" TO EACH SMOKE EMERGENCY PROCEDURE. USE PERMANENT METHODS COMMENSURATE WITH THE ORIGINAL DOCUMENT, SUCH AS TYPEWRITTEN, PLASTIC-COATED LABEL, ETC.

SIZE	FIG. NO.	DIRG. NO.	6003	REV.	A
B					
SCALE	LOCATION	6003003A	SHEET	3	of 4

2

1

A

B

A

B

